

G-SERIES

Atmosphere® Quarterly Cleaning And Maintenance Checklist

IMPORTANT! THIS QUARTERLY CLEANING AND MAINTENANCE IS TO BE PERFORMED BY THIRD PARTY SERVICE PROVIDERS ONLY!

This table represent the technician's checklist for cleaning & maintenance as well as its frequency.

- A. Visual checks of the tubes' interior and cleaning (if necessary) is to be performed for all applications.
- B. Filters are to be changed annually.
- C. During maintenance visits, the reverse osmosis unit's integrity must be verified by trained technicians; its conductivity is to be measured with a TDS meter; its membrane must be changed annually.

Type	Detail	1st Quarter	2nd Quarter	3rd Quarter	4th Quarter
Checking	24V DC Equipment	X	X	X	X
	Surroundings	X	X	X	X
	Filtration	X	X	X	X
	UV Filter	X	X	X	X
	Reverse Osmosis	X	X	X	X
	Equipment Functionality	X	X	X	X
	Fog Generation	X	X	X	X
	Error History	X	X	X	X
	Relay	X	X	X	X
	Unit Attachment	X	X	X	X
	Water Pressure	X	X	X	X
	Cable Tightening	X	X	X	X
	Hoses	X	X	X	X
	Cooling Fan	X	X	X	X
	Diffuser Piping	X	X	X	X
Cleaning	Nebulizer Unit	X	X	X	X
	Filtration System	X	X	X	X
	Diffuser Piping	X	X	X	X
	Fans & Guards	X	X	X	X
	Valve	X	X	X	X
Replacing	Ceramics		X		X
	Water Filters	X	X	X	X
	UV Filters				X
	Reverse Osmosis				X

SCC Internal Note: Any revisions to this document must also be made to 20-84857 & 20-85829.



888 E. Porter Road · Muskegon, MI 49441
 Phone: 231.798.8888 Fax: 231.798.4960 www.structuralconcepts.com

P/N 20-94739